

ERA

DACDRTS TS003 Heavy Duty Door Restrictor Fitting Instructions

This product is only suitable for installation on timber and solid core composite doors.

To fit a Door Restrictor you will require the following tools:

- Screwdriver
- Bradawl (or drill with 2.5mm drill bit)
- Pencil

Installing a Door Restrictor

- Select position for door restrictor.
- Mark screw holes for the restrictor on the door frame. Screw into position.
- Position hook on door level with the restrictor, ensuring the restrictor sits over hook, and screw into position.

Additional Information

Operation - Push the restrictor over the hook to restrict the door opening. Pull back restrictor away from door to enable the door to open.

Crime Prevention Tip - Always engage door restrictor and ask for identification before opening the door to strangers.

Safety Tip - For additional safety we recommend the use of an ERA 160° Door Viewer or ERA 180° Door Viewer.

Maintenance - Use a moist cloth only as household abrasives or solvents may affect surface finish.

Technical Information

TS003 Standard
BS 8213-1:2004
PAS 24:2012

Requirements:

Door opening impacts (abuse mode) - The product and its fixings shall resist 200 door opening impacts when subjected to an opening force of 100 N.

Door opening impacts (attack mode) - The product and its fixings shall be subjected to 3 impacts, after which the door opening shall not exceed 25mm at the point of disengagement or 76mm "on guard" position.

