

172 Dummy Knob Set - Face Fixing Fitting Instructions

Installing a Dummy Knob Set

To fit a Dummy Knob Set you will require the following tools: - Posidriv Screwdriver

- A Remove the screw cover from the plate, you will note one side of the plate has one tongue and the other has three, insert the two screws with the three tongues facing down.
- B When replacing the screw cover you will note a gap in the plate this needs to be placed over the section with the three tongues, click into position.
- Inside the knob handle is a notch, place this in line with the slot on the screw plate and carefully push and twist into position.

Removing the Knob Set

On the side of the screw cover plate is a small hole, carefully insert a small screwdriver into the hole whilst slightly pulling the knob handle, this will release the handle allowing you to remove the screw plate. Fix as above.

